
QM10512 Mount-QCHF (Quick Change Hopping Foot Adapter)


Back Ground Information:

We recently found a batch of Quick Change Hopping Foot mount adapters that have small bulges of raised material near the tapped/threaded hole for the screw that holds the foot on. The raised material at the sides of the hole on both sides appear to be from the countersinking process of the hole. Apparently the last step of polishing these bulges off was missed on this batch. Unfortunately this issue was found after some of these adapters had been used in QM00841 Handi Feet Conversion Kits. At this time we do not believe these foot adapters were used on machines.

Symptoms:

The Glide Foot 3 will not go all the way onto the QCHF mount adapter but only to the tapped/threaded hole.

Solutions:

 **Note:** Use the Glide Foot 3 as a gauge early and often to know when the raised material has been removed enough for it to fit properly.

- Use a medium (100-160) emery cloth to remove the raised material on each side of the hole and on both sides of the adapter as needed.
- Use a hard Arkansas Stone, to stone off the small ridge of material on each side of the hole and on both sides of the adapter as needed.
- Contact Handi Quilter to have a replacement QM10512 QCHF mount adapter sent out if needed.

